



# Instrucciones PDF

Usted puede leer las recomendaciones de la guía del usuario, la guía técnica o la guía de instalación para JVC GR-DV3000. Encontrarás las respuestas a todas sus preguntas sobre la JVC GR-DV3000 en el manual del usuario (información, especificaciones, consejos de seguridad, tamaño, accesorios, etc). Las instrucciones detalladas para la utilización aparecen en la Guía del usuario.

**Manual de instrucciones JVC GR-DV3000**  
**Instrucciones de uso JVC GR-DV3000**  
**Manual de usuario JVC GR-DV3000**  
**Guía del usuario JVC GR-DV3000**  
**Modo de empleo JVC GR-DV3000**

# JVC

DIGITAL VIDEO CAMERA  
**GR-DV3000**

Please visit our Homepage on the World Wide Web and answer our Consumer Survey (in English only):  
<http://www.jvc-victor.co.jp/english/index-e.html>

For Accessories:  
<http://www.jvc-victor.co.jp/english/accessory/>



**INSTRUCTIONS**

ENGLISH

## CONTENTS

<b>AUTOMATIC DEMONSTRATION</b>	<b>7</b>
<b>GETTING STARTED</b>	<b>8 - 17</b>
<b>BASIC RECORDING</b>	<b>18 - 24</b>
Recording On Tape .....	18
Recording On Memory Card .....	21
Recording On Tape And Memory Card .....	22
<b>BASIC PLAYBACK</b>	<b>25 - 27</b>
Playback From Tape .....	25
Playback From Memory Card .....	26
<b>USING MENUS FOR DETAILED ADJUSTMENT</b>	<b>28 - 33</b>
<b>ADVANCED FEATURES</b>	<b>34 - 53</b>
<b>CONNECTIONS</b>	<b>54 - 57</b>
Basic Connections .....	54
Advanced Connections .....	56
<b>DUBBING</b>	<b>58 - 61</b>
Dubbing To A VCR .....	58
Dubbing From A VCR .....	59
Dubbing To Or From A Video Unit Equipped With A DV Connector .....	60
Dubbing Still Images Recorded On A Tape To A Memory Card .....	61
<b>USING THE REMOTE CONTROL UNIT</b>	<b>62 - 73</b>
Slow-Motion Playback, Frame-By-Frame Playback and Playback Zoom .....	64
Playback Special Effects .....	65
Random Assemble Editing .....	66
For More Accurate Editing .....	70
Insert Editing .....	71
Audio Dubbing .....	72
<b>TROUBLESHOOTING</b>	<b>74 - 79</b>
<b>USER MAINTENANCE</b>	<b>80</b>
<b>INDEX</b>	<b>81 - 88</b>
Jack Box .....	81
Controls, Connectors And Indicators .....	82
Indications .....	84
<b>CAUTIONS</b>	<b>89 - 91</b>
<b>TERMS</b>	<b>92 - 93</b>
<b>SPECIFICATIONS</b>	<b>94 - 95</b>

LYT0940-001A

**EN**



[Tus instrucciones](#)  
[JVC GR-DV3000](#)

#### **Manual de resumen:**

Use the JVC BN-V408U/V416U/ V428U battery packs and, to recharge them, the provided multi-voltage AC Power Adapter/Charger. (An appropriate conversion adapter may be necessary to accommodate different designs of AC outlets in different countries.) When the equipment is installed in a cabinet or on a shelf, make sure that it has sufficient space on all sides to allow for ventilation (10 cm or more on both sides, on top and at the rear). Do not block the ventilation holes. (If the ventilation holes are blocked by a newspaper, or cloth etc. the heat may not be able to get out.) No naked flame sources, such as lighted candles, should be placed on the apparatus. When discarding batteries, environmental problems must be considered and the local rules or laws governing the disposal of these batteries must be followed strictly. The apparatus shall not be exposed to dripping or splashing. Do not use this equipment in a bathroom or places with water.

Also do not place any containers filled with water or liquids (such as cosmetics or medicines, flower vases, potted plants, cups etc.) on top of this unit. (If water or liquid is allowed to enter this equipment, fire or electric shock may be caused.) **WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.** Caution: (applies to Jack Box) To reduce the risk of fire, do not remove cover.

No user-serviceable parts inside. Refer servicing to qualified service person. **EN** Do not point the lens or the viewfinder directly into the sun. This can cause eye injuries, as well as lead to the malfunctioning of internal circuitry. There is also a risk of fire or electric shock.

**3 CAUTION!** The following notes concern possible physical damage to the camcorder and to the user. When carrying, be sure to always securely attach and use the provided shoulder strap. Carrying or holding the camcorder by the viewfinder and/or the LCD monitor can result in dropping the unit, or in a malfunction. Take care not to get your finger caught in the cassette holder cover. Do not let children operate the camcorder, as they are particularly susceptible to this type of injury. Do not use a tripod on unsteady or unlevel surfaces. It could tip over, causing serious damage to the camcorder. **CAUTION!** Attaching the Jack Box to the camcorder with cables (S-Video, Editing, DC, etc.) connected, then leaving it on top of the TV is not recommended, as tripping on the cables will cause the camcorder to fall, resulting in damage. Attach only the optional JVC VL-V3U Video Light, VL-F3U Video Flash or MZ-V3U Stereo Zoom Microphone to the camcorder's Info-Shoe.

This camcorder is designed exclusively for the digital video cassette, SD Memory Card and MultiMediaCard. Only cassettes marked " " and memory cards marked " " or " " can be used with this unit. Before recording an important scene . make sure you only use cassettes with the Mini DV mark or make sure you only use memory cards with the mark . remember that this camcorder is not compatible with other digital video formats remember that this camcorder is intended for private consumer use only. Any commercial use without proper permission is prohibited. (Even if you record an event such as a show, performance or exhibition for personal enjoyment, it is strongly recommended that you obtain permission beforehand.) " **SOME DO'S AND DON'TS ON THE SAFE USE OF EQUIPMENT** This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured. **DO DO** read the operating instructions before you attempt to use the equipment. ensure that all electrical connections (including the mains plug, extension leads and interconnections between pieces of equipment) are properly made and in accordance with the manufacturer's instructions.

Switch off and withdraw the mains plug when making or changing connections. **DO** consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment. **DO** be careful with glass panels or doors on equipment. **DON'T** continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way -- switch off, withdraw the mains plug and consult your dealer..



[Tus instrucciones](#)  
[JVC GR-DV3000](#)